F1

ALIVING DINOSAUR

MADE IN CHINA

FOR AGES 10 &

TWO AG13 OR LR44 BATTERY REQUIRED

CE
Grossistservice
Box 1430
171 27 SOLNA

Varning!
Ej lampling för barn under
3år innehåller smådelar
Ej sovelju alle 3-vuottaille
lapsille. Sisältää pieniä osia



CE

Grossistservice
Box 1430
171 27 SOLNA

Varning!
Ej lämpling för barn under
3 år innehåller smådelar
Ei sovellu alle 3-vuotiaille
lapsille. Sisältää pieniä osia

FOR AGES 10 &


TWO AG13 OR IR44 BATTERY REQUIRED

MADE IN CHINA

ALIVING DINOSAUR



USER'S MANUAL



FUNCTIONS OF EACH KEY

· A SELECT · B CONFIRM

· C RETURN TO THE NORMAL PICTURE

SET TIME

· PRESS RESET KEY TO CLEAN ALL MEMORIES

· PRESS KEY B TO DISPLAY TIME

· PRESS KEY A TO SET HOUR, PRESS KEY B TO SET MINUTE, PRESS KEY C TO START CLOCK

AFTER SET TIME, WAIT 2~10 MINUTES UNTILL DINOSAUR BORN, THEN BEGIN TO REAR

FEEDING YOUR PET

· PRESS KEY A TO SELECT FEEDING PICTURE

· PRESS KEY B TO CONFIRM THE FUNCTION

MEAL COMFIT

· THEN USE KEY A TO SELECT A KIND OF FOOD AND PRESS KEY B TO FEED YOUR PET

· PRESS KEY C TO RETURN THE NORMAL PICTURE

LIGHT ON AND OFF

· TURN OFF THE LIGHT WHILE PET IS SLEEPING AND TURN ON THE LIGHT IF PET IS AWAKE

· PRESS KEY A TO SELECT LIGHT PICTURE , PRESS KEY B TO CONFIRM THE FUNCTION

· IT'S DARK AT PM 7:00, THE SCREEN WILL BECOME BLACK. YOU CAN TURN ON THE LIGHT

· THE SCREEN WILL CLOSE AUTOMATICALLY AFTER PET HAS SLEEPED 5 SECONDS, THE SCREEN

WILL RESUME WHEN PET WAKE ABOUT ONE HOUR AGO.

PLAYING WITH YOUR PET

· PRESS KEY A TO SELECT PLAYING PICTURE

· PRESS KEY B TO CONFIRM THE FUNCTION

· PRESS KEY A AND B TO SELECT NAPKIN OR SCISSORS OR STONE AND PLAY WITH PET. PLAY 3 TIMES FINALIZE WIN OR LOSS.

NAPKIN SCISSORS STONE

MEDICATING

IF YOUR PET IS SICK, THE SICK INDICATOR DISPLAY ON THE SCREEN. SELECT THE MEDICAL TREATMENT PICTURE TO GIVE PET INJECTIONS UNTILL IT WILL RECOVER.

CLEAN UP THE DUNG

WHENEVER YOU SEE "DUNG" ON THE SCREEN。YOU CAN SELECT CLEAN PICTURE TO DO CLEANING FOR YOUR PET.

HEALTH CARE INDEX

PRESS KAY A TO SELECT THIS FUNCTION THEN PRESS KEY B CONTINUALLY , YOU MAY REVIEW AS FOLLOW :



AGE AND WEIGHT DISCIPLINE INDEX HUNGARY INDEX HAPPY INDEX

DISCIPLINE YOUR PET

SOMETIMES YOUR PET CALLS BUT HAS NOT ANY REASONS, YOU SHOULD DISCIPLINE IT AT THIS MOMENT. PRESS KEY A TO SELECT THE PICTURE AND PRESS KEY B TO DISCIPLINE IT

CALLING PICTURE

THE CALLING SYMBOL WILL DISPLAY ON THE SCREEN IF ANY CONDITIONS OF THE PET IS NOT GOOD. FOR EXAMPLE: SICK, DUNG, HUNGARY , ETC. WATCHING WHAT PET NEEDS AND DO IT.


CHANGE BATTERIES: REMOVE TWO SCREWS ON THE BACK COVER, TAKE OUT OLD BATTERIES. PUT IN NEW BATTERIES ACCORDING TO POLE MARKED AND SET BACK COVER. POWER OF MACHINE MAY KEEP 10 SECONDS AFTER POWER OFF.

BATTERIES MODEL: AG13 OR LR44 BUTTON BATTERY × 2

使 用 說 明 書

各鍵功能

A ・選擇　B ・確定　C ・回正常狀態



時間設定

・按 RESET 鍵可清除所有記憶
・按 B 鍵進入時間顯示，按 A 鍵設置 “時” ，按 B 鍵設置 “分”
・按 C 鍵啓動時鐘，按 B 鍵返回孵化畫面
時間設定後，須等 2-10 分鐘蛋殼破裂恐龍孵出後，才可開始喂養。


喂　食

飯　糖果

・按 A 鍵選擇喂食之功能，按 B 鍵確定。
・按 A 鍵選擇食物，按 B 鍵喂食。

開、關燈

・按 A 鍵選擇開關燈功能，按 B 鍵確定。
・晚 7 點天黑了，屏幕會變黑，要幫小龍開燈。
. 小龍睡覺 5 秒鐘后，屏幕會自動關閉。早晨小龍醒來前 30 - 50 分鐘，屏幕自動恢復。
ON　開燈　　OFF　關燈



游戲（布、剪、錘）

・按 A 鍵選擇玩游戲，按 B 鍵確定。
. 按 A 鍵及 B 鍵選擇布、剪、錘與小龍一起玩游戲，玩三次（有輸贏的）爲一局。
. 按 C 鍵返回正常狀態。

看醫生


・當小龍生病時，會有 出現，按 A 鍵選擇看醫生，按 B 鍵給小龍打針。

清　掃

・當小龍便便時， 要替小龍清掃。按 A 鍵選擇清掃功能， 按 B 鍵清掃。

小龍的狀態

・按 A 鍵選擇觀察小龍的狀態，連續按 B 鍵，你可知小龍的年齡、體重、教育程度、肚子飽不飽、感覺和開心程度。



年齡與體重　教育程度　肚子飽不飽　感受

教育

・當小龍不是肚子餓、生病、便便、想玩，卻沒理由的呼叫時，即需要教育。
・按 A 鍵選擇教育功能，按 B 鍵教育小龍，不需要教育時，小龍會生氣。

小龍呼叫

・當小龍肚子餓、生病、便便、想玩時，會發出呼叫。觀察小龍需要什么并爲它完成。

更換電池： 卸下後蓋的兩顆螺釘，取出舊電池，將新電池按標示的極性放入并安裝好後蓋。機內電源在斷電后可維持 10 秒鐘。

電池型號： AG13 或 LR44 扣式電池兩枚


Resumé